

FOUNDATIONS POURING . CONTINUED

YOU ARE NOW READY TO POUR IN THE CONCRETE !

ORDER REDIMIX CONCRETE OF A STRENGTH ADVISED BY YOUR ENGINEER. YOU WILL NEED AT LEAST 5 CUBIC METRES PLUS ALLOW FOR SOME WASTAGE.

NOTE

TELL REDIMIX COMPANY THAT IT IS FOR USE IN FOUNDATIONS

DEPENDING ON THE SITE AND THE KIND OF TRUCK HE WILL EITHER BE ABLE TO POUR DIRECTLY INTO THE HOLE, OR THE DIGGER WILL HAVE TO HELP.

POUR IN THE RIGHT AMOUNT, AND LEVEL IT OFF WITH A PIECE OF TIMBER

